

# Instruction Manual

## Gerrelt A-Pillar Deflectors



### ***Painting***

The used filler, primer or paint must be suitable for plastic (the deflectors are made out of polystyrene). Wet sand with 600 waterproof, and then spray filler or primer over it. Then wet sand again with 600, and then paint.

### ***Assembly***

#### **Needed materials**

- A bit string that is longer than the A-pillar, and about 3 mm thick (just like the string one would use with the installation of a windshield)
- Optional: painters masking tape
- Optional: a medium-sized screwdriver

## Preperation

Press the string under the windscreen rubber on the A-pillar. Let the ends hang out.

If you put some painters masking tape around the head of a screwdriver, you can use it to press the string under the rubber.

Please be very careful! Be careful not to damage the rubber or the paint!



Now, take the A-pillar deflector and remove a small piece of the protection of the double sided tape. Fold this piece in a corner so that it just comes out under the deflector.



This allows you to position the deflector before you remove the protection of the tape and it sticks to the car.

## Attaching

Hook the deflector behind the gutter, and put the other side against the window rubber.

While pressing the deflector against the rubber: pull the string out from under the rubber. The rubber should fall over the edge of the deflector.



It may be that you need two people. Sometimes the deflector escapes from the rubber at the bottom, while you are working at the top. The second person can then hold the deflector under the rubber.

You can also use painters masking tape to secure the deflector under the rubber, like in these pictures:





When the deflector edge is under the rubber, ensure that it is under the rubber far enough. Now you can position it in the right location.



The deflector can be moved up and down a bit.

Remove the protection of the double-sided tape (which you have folded in a corner) and apply pressure for some time to make the tape adhere to the car properly. The double sided tape is removable, in case you want to remove the deflectors on a later date.



Ready! Now don't forget to do the other side...